# 套接字编程作业 5-1: ICMP ping 程序

本作业要求理解 ICMP 协议,掌握使用 ICMP 请求和响应消息实现 Ping 程序。

Ping 是一个流行的网络应用程序,用于测试 IP 网络中的某个特定主机是否可达。它也可用于测量客户主机和目标主机之间的网络延迟。它的工作过程是:向目标主机发送 ICMP"回显(Echo)"报文(即 ping 分组),并监听 ICMP"回显响应(Echo reply)"应答(有时也称为 pong 分组)。ping 程序测量往返时间(RTT),记录分组丢失,并计算多个 ping-pong 交换的统计汇总(往返时间的最小值、最大值、平均值和标准差)。

在这个编程作业中,你的任务是使用原始套接字(RAW Socket)开发自己的 Ping 程序。你的程序将使用 ICMP,但为了保持简单,将不完全遵循 RFC 1739 中的官方规范。请注意,你只需要编写 ping 客户端程序,因为服务器侧所需的功能内置于所有的操作系统中。

# 任务 1、编写 ping 客户端代码

请在"ping 客户端框架代码.py"中标有#Fill-in-start 和#Fill-in-end 的地方填写代码,每个地方都可能需要不止一行代码。

你的 ping 程序需具有如下功能:

1) ping 程序的命令格式:

#### client.py destination\_host [-n count]

其中: *client.py* 是客户端程序文件名; *destination\_host* 是目标主机的域名地址; -n *count* 选项用来指定发送的 ping 分组个数,如不使用该选项则默认发送 4 个 ping 分组。

"ping 客户端框架代码.py"框架代码已给出了完整的 ping 命令解析代码。

2) Ping 程序发送的 ping 分组之间间隔大约一秒钟,每个 ping 分组的 ICMP 数据字段携带一个时间戳。每个 ping 分组发送完后,程序最多等待一秒,用于接收响应。

如果一秒后没有收到响应,那么应假设 ping 分组或 pong 分组在网络中丢失(或者目的主机已关闭),并显示如下信息:

### Request timed out

如果收到目的主机返回的 pong 分组,则显示如下信息:

Reply from *ip\_address*: bytes=*data\_bytes* time=*rtt* ms TTL=*TTL\_value* 

其中: *ip\_address* 是发送响应报文的主机 IP 地址; *data\_bytes* 是响应报文中 ICMP 数据字段的字节长度; *rtt* 是以毫秒(ms)为单位的往返时间(RTT), *TTL\_value* 是 pong 分组的 IP 首部中的生存时间(TTL)字段值。

框架代码中提供了发送一个 ping 分组的完整代码——"sendOnePing"方法,以及

计算 ICMP 报文校验和的完整代码——"checksum"方法。在接收一个 pong 分组的 "receiveOnePong"方法中,你需要提取 ICMP 分组首部中的报文类型、校验和、ID 等信息来检查接收的 ICMP 分组是否有效;此外还需要提取 IP 分组首部中的 TTL、长度以及 ICMP 分组数据字段,以生成 ping 程序要显示的信息。

请在尝试完成"receiveOnePong"方法之前,先仔细研究"sendOnePing"方法和"checksum"方法。特别注意网络字节序问题!

- 3) ping 程序发送和接收完所有 ping-pong 分组后,要统计并显示(格式自定义)以下信息:
  - 已发送的 ping 分组数量、已接收的 pong 分组数量、丢包数量和丢包率;
  - 以毫秒(ms)为单位的最小、最大和平均 RTT。

## 任务 2、测试 ping 客户端程序

首先,通过发送分组到本地主机来测试你的客户端,目的主机地址是 127.0.0.1。 然后,分别 Ping 位于国内的 2 个目的主机和位于国外的 2 个目的主机,以测试你的 ping 程序。

这个作业要求使用原始套接字,因此在某些操作系统中,可能需要管理员/root 权限才能运行你的 Ping 程序。

# 任务 3\*、解析并显示 ICMP 响应错误(选做)

任务 1 编写的 Ping 程序只能检测收到 ICMP 回显响应报文或没有收到响应。请修改 Ping 程序,解析 ICMP 的目的不可达错误代码,并向用户显示相应的错误结果。教材图 5-19 给出了常见的 ICMP 响应错误码。

# 作业提交要求

任务1和2必做,任务3选做。

将以下内容压缩打包后提交,压缩文件的命名规则为"作业 5-1-学号-姓名":

- 1) 任务 1 的完整 ping 客户端代码文件
- 2)运行结果报告文件,包含:
  - Python 版本
  - 任务 2 的 ping 客户端程序运行窗口截图
- 3)可选提交:任务 3 的 ping 客户端代码文件 1 份,以及运行结果报告 1 份(包含客户端运行窗口截图)

# ping 客户端框架代码

```
from socket import *
import os
import sys, getopt
import struct
import time
import select
import binascii
ICMP_ECHO_REQUEST = 8
def checksum(string):
    csum = 0
    countTo = (len(string) // 2) * 2
    count = 0
    while count < countTo:
         thisVal = string[count] * 256 + string[count+1]
         csum = csum + thisVal
         csum = csum & 0xffffffff
         count = count + 2
    if countTo < len(string):</pre>
         csum = csum + string[len(string) - 1]
         csum = csum & 0xffffffff
    csum = (csum >> 16) + (csum & 0xffff)
    csum = csum + (csum >> 16)
    answer = ~csum
    answer = answer & 0xffff
    answer = answer >> 8 | (answer << 8 & 0xff00)
    return answer
def receiveOnePong(mySocket, destAddr, ID, sequence, timeout):
    timeLeft = timeout
    while 1:
         startedSelect = time.time()
         whatReady = select.select([mySocket], [], [], timeLeft)
         howLongInSelect = (time.time() - startedSelect)
         if whatReady[0] == []: # Timeout
              return None
         timeReceived = time.time()
         recPacket, addr = mySocket.recvfrom(1024)
         #Fill in start
         #Fetch the ICMP header from the IP packet
         #Fill in end
         timeLeft = timeLeft - howLongInSelect
         if timeLeft <= 0:
              return None
```

```
def sendOnePing(mySocket, destAddr, ID, sequence):
    # Header is type (8), code (8), checksum (16), id (16), sequence (16)
    myChecksum = 0
    # Make a dummy header with a 0 checksum
    # struct -- Interpret strings as packed binary data
    header = struct.pack("!BBHHH", ICMP_ECHO_REQUEST, 0, myChecksum, ID, sequence)
    data = struct.pack("!d", time.time())
    # Calculate the checksum on the data and the dummy header.
    myChecksum = checksum(header + data)
    # Get the right checksum, and put in the header
    if sys.platform == 'darwin':
         # Convert 16-bit integers from host to network byte order
         myChecksum = htons(myChecksum) & 0xffff
    else:
         myChecksum = htons(myChecksum)
    header = struct.pack("!BBHHH", ICMP_ECHO_REQUEST, 0, myChecksum, ID, sequence)
    packet = header + data
    mySocket.sendto(packet, (destAddr, 1)) # AF_INET address must be tuple, not str
    # Both LISTS and TUPLES consist of a number of objects
    # which can be referenced by their position number within the object.
def doOnePing(destAddr, ID, sequence, timeout):
    icmp = getprotobyname("icmp")
    # SOCK_RAW is a powerful socket type. For more details:
    #http://sock-raw.org/papers/sock_raw
    #Fill in start
    #Create Socket here
    #Fill in end
    sendOnePing(mySocket, destAddr, ID, sequence)
    rtt = receiveOnePong(mySocket, destAddr, ID, sequence, timeout)
    mySocket.close()
    return rtt
def ping(dest, count):
    # timeout=1 means: If one second goes by without a reply from the server,
    # the client assumes that either the client's ping or the server's pong is lost
    timeout = 1
    myID = os.getpid() & 0xFFFF # Return the current process i
    loss = 0
    # Send ping requests to a server separated by approximately one second
    for i in range(count):
         result = doOnePing(dest, myID, i, timeout)
         #Fill in start
```

```
#Print response information of each pong packet:
          #No pong packet, then display "Request timed out."
          #Receive pong packet, then display "Reply from host_ipaddr: bytes=... time=... TTL=..."
          #Fill in end
          time.sleep(1)# one second
     #Fill in start
     #Print Ping statistics
    #Fill in end
    return
if __name__ == "__main__":
    if len(sys.argv) < 2:
          print('IcmpPing.py dest_host [-n <count>]')
          sys.exit()
    host = sys.argv[1]
    try:
          dest = gethostbyname(host)
    except:
          print('Can not find the host "%s". Please check your input, then try again.'%(host))
          exit()
    count = 4
    try:
          opts, args = getopt.getopt(sys.argv[2:], "n:")
     except getopt.GetoptError:
          print('IcmpPing.py dest_host [-n <count>]')
          sys.exit(2)
     for opt, arg in opts:
          if opt == '-n':
               count = int(arg)
    print("Pinging " + host + " [" + dest + "] using Python:")
    print("")
    ping(dest, count)
```